

CF01

Suzuki DR 750 BIG

Fitting kit:

ID	Description	Cat.n	Qt
1	Crash bars	CF01	-
2	UP bracket	X55	1
3	Down bracket	X56	1
4	UP special U bolt M10 stirrup	X51	1
5	Washer M8	988	2
6	Bolt M8x25	833	2
7	Bolt M8x80	843	1
8	Nut M8 lock nut	809	1
9	Nut M10 lock nut	810	2
10	Washer M10	804	4
11	3M tape	3M	1
12	Plastic cover M10x35	X35	2
13	Bolt M10x30	882	2
14	Stickers	-	2

Instruction:

- Installation of the left and right crash frame make according to the attached photos below.
- Remove the original bolt M8 on the frame in front of the engine.
- Give the steel adapter to this place and use the bolt M8x80mm together with nut M8 for mounting (don't tighten, leave the nut free).
- Remove the original bolt M8 on the right side of the frame of the motorcycle (rear gripping, above driver's foot pegs).
- Take crash frame for the right side and give it into the steel adapter before the engine. Use the bolt M8x25mm for tightening of crash frame in the rear. Use the spring pad M8 under the bolt.
- Take the steel adapter and by stirrup (...mm) mount it on the frame of the motorbike, under the stirrup stick 3M tape.
- Do not tighten the stirrup, put it in the position to upper right handle on the crash frame and use the bolt M10x30mm and lightly tighten it. Under the screw use the spring pad M10.
- Now you have lightly mounted the right crash frame.
- Give the crash frame for the left side into the bottom steel adapter. Use the bolt M8x25mm for tightening of crash frame in the rear. Use the spring pad M8 under the bolt.
- Use the bolt M10x30mm for gripping to upside steel adapter. Use the spring pad M10 under the bolt.
- Now you have crash frames mounted on the motorcycle, you can tighten everything.
- Give the plastic covers on bolts M10x30mm, which connect the crash frames together with upside steel adapter.

- **Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).**

