

CF55


Lower

Honda CRF 1000 Africa Twin '16-



Fitting kit:

ID	Description	Cat.N	Qt
1	Spacer d=5, hole dia. 8,5	433	1
2	Spacer d=17, hole dia. 8,5	1190	1
3	Bolt M8x130	884	1
4	Washer M8 flat	802	2
5	Nut M8 safety	809	1

Note: Use medium strong glue during assembly on the all threads.



Dismantle original bolt M8 from chassi. Insert washer ID.4 ont he bolt from left side, put crash bar and spacer l=17mm from left side of the bike. Put frame on the chassi. Inset spacer l=5mm, crash bar, washer and tighten it from the right hand side.



Use original bolts for rear gripping crash bars.