

CF69

Honda NC750S 2016-

Kit for left side

	Description	Cat. no.	Pcs
1	Crash frame		1
2	silentblok	X34	1
3	M8 thread	813	1
4	3M tape		1
5	RD moto sticker		1

Kit for right side

	Description	Cat No.	Pcs
1	Crash frame		1
2	silentblok	X34	1
3	M8 thread	813	1
4	3M tape		1
5	RD moto sticker		1

Assembly:

1. Take off the lower pastic under the engine
2. Fit in the silentblocks into the crashframes, including the nuts
3. Crash frames for both left and right side fit under the original screws (acc to photos), but do not tighten them up yet

Right side



Left side

