

CF77

Kawasaki ER6N 2009-2011

Left side kit:


ID	Description	Cat.No.	Pcs
1	Crash frame	CF77KD	1
2	Bolt M10x90	880	1
3	Nut M10	814	1
4	Bolt M6x40	865	1
5	3M tape		1

Right side kit:

ID	Description	Cat.No.	Pcs
1	Crash frame	CF77KD	1
2	Bolt M10x100	879	1
3	Nut M10	814	1
4	Bolt M6x40	865	1
5	Steel connecting bracket 288mm	X88	1
6	Bolt M10x30	888	2
7	Washer M10 (spring)	801	2
8	Washer M10	804	2
9	Dural. cylinder - 6mm	DV115	1

Instructions:

We recommend to use the glue on all threads (medium strong).



Remove original bolt, and place frames under plastic cover.


Use bolt M6x40 for tightening.

Remove original bolt and stick 3M tape on the motorcycle. Mount original bolt back.

Bolt M10x90 + washer M10.

For tightening use safety nut M10.

Leave original cylinder between frame and engine.



Bolt M10x90 + washer M10.

Use safety nut M10 for tightening.

Leave original cylinder between frame and engine.

Remove original bolt, and place frames under plastic cover. Insert cylinder ID9 between moto and crash frame. Replace original bolt using bolt M6x40.



Remove original bolt and stick 3M tape on the motorcycle. Mount original bolt back.

Mount steel bracket (ID.5) using bolts (ID.6). Dont forget to place washers (ID.8) and (ID.7).