



K44S

Kawasaki Ninja 650 2017-

Left side kit:

| ID | Description | Cat.no. | Pcs |
|----|----------------|---------|-----|
| 1 | Adapter | DV-318 | 1 |
| 2 | Adapter | DV-4 | 1 |
| 3 | Bolt M6X25 | 877 | 3 |
| 4 | Bolt M4X16 | 876 | 2 |
| 5 | Bolt M10x150 | 939 | 1 |
| 6 | Safety nut M10 | 810 | 1 |

Right side kit:

| ID | Description | Cat.no. | Pcs |
|----|----------------|---------|-----|
| 1 | Adapter | DV-318 | 1 |
| 2 | Adapter | DV-144 | 1 |
| 3 | Bolt M6X25 | 877 | 3 |
| 4 | Bolt M4X16 | 876 | 2 |
| 5 | Bolt M10x160 | 979 | 1 |
| 6 | Safety nut M10 | 810 | 1 |

Instructions:

- 1.) Unscrew original bolt from the frame of motorcycle according to the picture.
- 2.) Put both adapters ID1 and ID2 on the bolt M10.
Note: Longer bolt is on the right
- 3.) Mount this kit on the frame of motorcycle using safety nut M10.
- 4.) Mount slider on the adapter using three bolts M6.
- 5.) In the end mount coloured cover into slider using two bolts M4.

We recommend to use the glue on all threads.

