



Instruction right side:

1. Take out fairing.
2. To give way bolts on coolant.
3. Dismantle original bolts from frame and mount dural. bracket ID.1 use bolts ID5.
4. Mount duralumin bar ID.7 and use bolts ID.6.

Instruction left side:

1. Take out fairing.
2. Mount dural. bracket ID.1 use special clevis from back side ID.2 and use bolts ID7.
3. Stick 3M tape on the frame ID.12, not to scratch frame
4. Mount dural. bar use bolt ID.6

Mount fairing and coolant back to bike.

Instruction to assembly for protectors:

1. Insert bolts ID. 5 into the dural.adapter for SL01 ID.4 a ID.3 after dural.cylinder ID.3 and ID.2
2. This set mount on the bike.
3. Mount slider ID.10, insert colour caps ID.9, use bolts ID.11

Use glue of all threads.



S35S

Suzuki GSX 1250FA 2010

Kit for left side:

ID	Description	Cat.n	Qty
1	Dural.holder for SL01	664	1
2	Dural. special clevis	665	1
3	Dural.cylinder	296	1
4	Dural adapter	DV314	1
5	Bolt M12x110x1,25	910	1
6	Bolt M6x30	863	1
7	Bolt M6x50	867	2
8	Slider	SL01	1
9	Cap	SLcap	1
10	Bolt M6x25	877	3
11	Bolt M4x16	876	2
12	3M tape	3M	2

Kit for right side:

ID	Description	Cat.n	Qty
1	Dural.holder for SL01	666	1
2	Dural.cylinder	296	1
3	Dural. adapter	DV314	1
4	Bolt M12x110x1,25	910	1
5	Bolt M10x50x1,25	921	2
6	Bolt M6x30	863	1
7	Dural.bar	667	1
8	Slider	SL01	1
9	Cap	SLcap	1
10	Bolt M6x25	877	3
11	Bolst M4x16	876	2
12	3M tape	3M	2

