

# Y33S

## Yamaha MT07 2014

### Kit for left side:

| ID. | Description      | Cat.no | QTY |
|-----|------------------|--------|-----|
| 1   | Slider           | SL01   | 1   |
| 2   | Dural. Cylinder  | DV341  | 1   |
| 3   | Bolt M12x80x1,25 | 908    | 1   |
| 4   | Bolt M6x25       | 877    | 3   |
| 5   | Bolt M4x16       | 876    | 2   |
| 6   | Cover            | cap    | 1   |

### Kit for right side:

| ID. | Description      | Cat.no | QTY |
|-----|------------------|--------|-----|
| 1   | Slider           | SL01   | 1   |
| 2   | Dural. Cylinder  | DV341  | 1   |
| 3   | Bolt M12x80x1,25 | 908    | 1   |
| 4   | Bolt M6x25       | 877    | 3   |
| 5   | Bolt M4x16       | 876    | 2   |
| 6   | Cover            | cap    | 1   |

### **Instructions to assemble left side:**

1. Dismantle original bolt from frame.
2. Insert the dural.cylinder (ID2) into the frame .
3. Use the bolt M12x80 (ID3) and mounting slider (ID1) for this mounting use bolts (ID4).
4. Cover (ID6) into the slider and use the bolts M4 (ID5).

### **Instruction to assemble right side:**

1. Dismantle original bolt from frame.
2. Insert the dural.cylinder (ID2) into the frame .
3. Use the bolt M12x80 (ID3) and mounting slider (ID1) for this mounting use bolts (ID4).
4. Cover (ID6) into the slider and use the bolts M4 (ID5).

**Use the torque on threads for all connects.**

